




Multi-oscillator for Korg NTS-1, Minilogue XD and Prologue

<https://tsoniq.com/software/korg/unity>

unity

unity is a user oscillator for Korg Logue based synthesisers. It supports the NTS-1, Minilogue XD and Prologue.

unity takes inspiration from the JP8000's Super-Saw oscillator, extending it with a multi-model waveform generator, adjustable high-pass filter, overdrive and more.



With a newly initialised patch, **unity** produces just a single oscillator with the *Shape* control morphing between triangle and sawtooth forms.

Edit the *Density* parameter to add detuned oscillator pairs for a maximum of 19 oscillators per voice, and use the *Shift+Shape* control to adjust the detune.

Use the *Model* parameter to select a different set of waveforms, and the high-pass filter to further modify the sound.

Create dynamic waveforms by using the LFO to sweep the waveform shape, detune or high-pass filter.

Use the *Overdrive* parameter to give dense patches more bite.

Downloading and Feedback

The latest version can be downloaded from <https://tsoniq.com/software/korg/unity/>.

You can send feedback by email to logue@tsoniq.com, or leave a comment on the download page.


unity is free to use, but if you find the oscillator useful and would like to support future development on Korg platforms, consider making a donation via the download page.

Installation

unity is supplied as a zip archive containing separate files for each platform:

NTS1:	unity.ntkdigunit
Minilogue XD:	unity.mnlgxdunit
Prologue:	unity.prlgunit

Use the appropriate Librarian application (available from <https://korg.com>) to import the unit and then upload to the synthesiser.



Patch Parameters

Patch parameters can be edited from the front panel of the instrument.

The following parameters are provided:

Parameter	Range	Function
Model	1-10	Selects the waveform generator model. See below.
Density	1-10	<p>Sets the number of detuned oscillator pairs.</p> <p>A value of 1 gives just the central oscillator, while larger numbers add pairs of detuned oscillators with a spread controlled by the '<i>Shift-Shape</i>' control.</p> <p>The maximum <i>Density</i> setting of 10 gives the central oscillator plus up to 18 detuned oscillators spaced around the centre frequency, for a total of 19 oscillators (depending on <i>Model</i> setting and processor).</p>
HPF Cutoff	0-100%	<p>Sets the HPF cutoff frequency.</p> <p>The HPF tracks the oscillator frequency, with a positive offset controlled by the <i>HPF Cutoff</i> setting.</p>
HPF Resonance	0-100%	<p>Sets the HPF resonance.</p> <p>A value of zero corresponds to a flat pass-band, while increasing values will accentuate frequencies close to the fundamental.</p>
Overdrive	0-100%	<p>Sets the overdrive level.</p> <p>Increasing values result in apparently louder sound with increasing distortion. This can be helpful to thicken the sound if a high <i>Density</i> setting is used.</p>
Modulation	1-4 (NTS1) 1-6 (others)	Selects a predefined modulation source and destination. See below.

Model

The *Model* parameter switches between one of ten oscillator models, each providing a different source of adjustable waveforms.

There are band-limited and aliasing analogue waveform models, plus ring-modulation and 2-oscillator FM.

Note that for Ring Modulation and FM models the *Density* parameter will need to be greater than one for the modulation to be apparent.

<i>Model</i>	Description
1	Blend between band-limited Triangle and Sawtooth waveforms via the Shape control.
2	Blend between band-limited Square and Sawtooth waveforms via the Shape control.
3	Band-limited pulse, with adjustable width.
4	As Model 1, but without anti-aliasing.
5	As Model 2, but without anti-aliasing.
6	As Model 3, but without anti-aliasing.
7	As Model 1, but with phase reset to zero at key on and with reduced detune spread.
8	As Model 2, but with phase reset to zero at key on and with reduced detune spread.
9	As Model 3, but with phase reset to zero at key on and with reduced detune spread.
10	Ring modulation with sine-wave pairs. The shape control adjusts the detune.
11	Ring modulation with triangle/sawtooth pairs. The shape control adjusts the detune.
12	Ring modulation with sawtooth pairs. The shape control adjusts the detune.
13	Frequency modulated sine-wave pairs. The shape control adjusts the detune.
14	Frequency modulation sawtooth pairs. The shape control adjusts the detune and width.
15	Frequency modulation pulse-wave pairs. The shape control adjusts the detune and width.

Modulation

The *Modulation* parameter specifies the destination for LFO shape modulation. To use LFO modulation:

- set the *Modulation* parameter to a value other than 1
- set the LFO target to "Shape"
- set the LFO intensity to something other than zero
- settings 5 and 6 are available on the Minilogue XD only and allow filter sweeps to be controlled from the front panel filter controls

<i>Modulation</i>	Description
1	Off
2	The LFO controls the waveform (Shape).
3	The LFO controls the detune (Shift-Shape.
4	The LFO controls the HPF-Cutoff frequency.
5	The Filter Cutoff and resonance knobs control the HPF (Minilogue XD and Prologue only)
6	The Filter Cutoff and resonance knobs control the HPF, with the cutoff control inverted (Minilogue XD and Prologue only)

Emulating a Roland JP8000 Super-Saw Oscillator

Try the following:

Shape: 100%
Model: 5 (aliasing triangle-saw)
Density: 4 (central oscillator plus 3 detuned pairs)
HPF Cutoff: adjust to taste
HPF Resonance: 0
Overdrive: 0

CPU Limits

unity's detuned oscillator pairs are very CPU intensive, with a *Density* setting of 10 corresponding to 19 fully independent oscillators running at the same time on a single voice.

unity has been calibrated so that on a Minilogue XD, no overload should occur.

However, we are unable to test this on other hardware platforms, so if you experience unexpected audio glitches, back off the *Density* parameter until the output is clean - and please let us know so that we can update the software.

Model Number	Maximum Number of Oscillators Per Voice		
	NTS-1	Minilogue XD	Prologue
1	15	15	15
2	13	13	13
3	11	11	11
4	17	17	17
5	19	19	19
6	15	15	15
7	15	15	15
8	11	11	11
9	19	19	19
10	11	11	11
11	11	11	11
12	11	11	11
13	11	11	11
14	19	19	19
15	11	11	11



Copyright, Warranty and Liabilities

The copyright to *unity* is held by tSoniq. You can use the software freely without restriction, other than you may not modify, resell or misrepresent its ownership.

No warranty is implied. Any liability resulting from the use of this software is limited to the price that was paid.

Release History

Version	Release Date	Changes
1.0	8/Nov/2021	Initial release.
1.1	28/Dec/2021	Added Prologue control support. Improved HPF performance.